

1 **1.1.1 Functions**

2 *Editorial Note: This is subclause 6.3.4*

3 AddField(field_code, field_value)

4 This function is a method associated with structures used in the state diagrams. This method adds a
5 field, specified by field_code, to the structure and assigns that field the value specified by
6 field_value. The field_code parameter is one of the Field Code values specified in Table 6-2.

7